

BOX CONTENTS: 1 modem, 1 ethernet cable, 1 power cord.

### Step 1:

Plug your existing coax cable from the wall into the modem. A coax cable is required for rewave Internet, if your home doesn't have one, call us to arrange for a technician to install one.

### Step 2:

Plug the power cord into your wall outlet and the other end into the matching modem slot.

Your modem is now powering up. During this time, the lights will start flashing. When the lights are solid you are ready to go! It can take up to twenty minutes to finish.

### Step 3:

Now that you have internet, it's time to configure your Wi-Fi network:

- Go to your device's (computer, phone, etc) "Wireless Network Settings" and refresh the network list.
- Select your Network Name (SSID) from the list.
- Enter the 10-digit "Preshared Key" in the password field to connect to your network.

### Helpful Tip:

An ethernet cable is included in your package. Ethernet provides a direct line to the internet and can give larger devices, such as a television, a stronger connection. This can make devices run faster. To use it, just plug one end of the ethernet cable into the modem out-jack, and the other end into the device's port labeled "ethernet in".

That's it. Now you can connect all your wireless devices to your internet using your network name and password.

