

Connecting Your Phone to an ATA and Modem

1. Plug the power cord in from the ATA to the wall.
2. Plug the ethernet cord into the back of the ATA and into your modem.
3. Plug the phone cable from your regular phone into the back of the ATA.
4. Pick up the receiver – there should now be a dial tone.

